

## DOUBLE-SEAL® BALL VALVES FOR VACUUM SERVICE

Inherent features of the Jamesbury® ball valves make them well-suited for vacuum service.

### FEATURES

- Positive sealing - no through-leakage or in-leakage past the stem.
- Full unobstructed flow, decreasing evacuation time when pumping vacuums.
- 90° operation to open or close.
- Wide selection of materials to suit specific service conditions.
- Ability to seal in either direction - suitable for alternating vacuum-pressure processes.
- Resilient materials limited to polymeric seats, minimizing out-gassing problems.

Standard *Jamesbury* ball valves in all materials and sizes are rated to hold vacuums down to  $2 \times 10^{-2}$  Torr of absolute pressure.

For higher vacuums, *Jamesbury* high-vacuum series ball valves are recommended. These valves are

prepared with extremely close control of seat and seal tolerances to ensure complete tightness, and with special attention to quality of finished surfaces. Provision is made to vent and evacuate the body cavity. All components are specially cleaned, and valves are tagged, and then sealed in polyethylene bags.

Vacuum valves are guaranteed to have a leakage rate not to exceed  $1 \times 10^{-5}$  std.cc/sec. of helium. If required, high-vacuum valves can be tested and certified for this figure with a helium mass spectrometer having maximum sensitivity of  $2 \times 10^{-10}$  std.cc./sec.

Listed below are vacuum ratings and recommended temperature ranges of both standard and high-vacuum ball valves with PTFE or Xtreme® seats and PTFE or TFM stem seals.

Type of Valve	Temperature Range	Vacuum Rating
Standard valves- all sizes and styles	-50°F to +400°F -46°C to +204°C	To $2 \times 10^{-2}$ Torr
High-vacuum valves- all sizes and styles	0°F to +300°F -18°C to +149°C	Below $2 \times 10^{-2}$ Torr

	Pounds per square inch (psi)		Kilograms per square inch (kg/cm <sup>2</sup> )		Inches of water column (in. wc)		Inches of mercury (in. hg)		Millimeter of mercury (mm hg)		Microns (Torr x 1000)	Valve applications
	Gage	Absolute	Gage	Absolute	Gage	Absolute	Gage	Absolute	Gage	Absolute		
Pressure	3	18		1.266	100	500	6	36	100	900	760,000	Use standard valves
	2	16	0.141	1.125	50	450	3	33		800		
Atmosphere	0	14.7	0	1.033	0	406.8	0	29.92	0	760		
		14		0.984				27		700		
	2	12	0.141	0.844	50	350	3	24	100	600		
	3		0.281		100		6		200		20	Use V or VC High vacuum valves
Vacuum	4					300	9	21		500		
	5	10		0.703								
	14.6996	.0004 or $4 \times 10^{-4}$	1.03297	.00003 or $3 \times 10^{-5}$	406.79	.01 or $1 \times 10^{-2}$	29.91	.0008 or $8 \times 10^{-4}$	759.98	.02 or $2 \times 10^{-2}$		
		$2 \times 10^{-7}$		$1.36 \times 10^{-8}$		$5 \times 10^{-6}$		$4 \times 10^{-7}$		$1 \times 10^{-5}$		
	14.7	0	1.033	0	406.8	0	29.92	0	760	0	0	

## HOW TO ORDER

Specify the high vacuum version of Eliminator and Series 2000, 4000, 7000, or 9000 valves by inserting the letter "V" ("VC" for high vacuum certified valves) in the "Special Construction" location in the catalog code. For example, Style 7150V.

Subject to change without prior notice.

### **Metso Flow Control Inc.**

**Europe**, Vanha Porvoontie 229, P.O. Box 304, FI-01301 VANTAA, Finland.  
Tel. +358 20 483 150. Fax +358 20 483 151

**North America**, 44 Bowditch Drive, P.O. Box 8044, Shrewsbury, MA 01545, USA.  
Tel. +1 508 852 0200. Fax +1 508 852 8172

**South America**, Av. Independência, 2500- Iporanga, 18087-101, Sorocaba-São Paulo, Brazil.  
Tel. +55 15 2102 9700. Fax +55 15 2102 9748/49

**Asia Pacific**, 238B Thomson Road, #17-01 Novena Square Tower B, Singapore 307685.  
Tel. +65 6511 1011. Fax +65 6250 0830

**China**, 11/F, China Youth Plaza, No.19 North Rd of East 3rd Ring Rd, Chaoyang District, Beijing 100020, China. Tel. +86 10 6566 6600. Fax +86 10 6566 2583

**Middle East**, Roundabout 8, Unit AB-07, P.O. Box 17175, Jebel Ali Freezone, Dubai, United Arab Emirates. Tel. +971 4 883 6974. Fax +971 4 883 6836

**[www.metso.com/valves](http://www.metso.com/valves)**

